

TAKE THIS DOOR STRAIGHT TO PAINT WITH THESE 5 STEPS:

STEP 1:

- Sand all surfaces with 320 grit film sheet.
(A SurfPrep 3x4 sander works great for this!)
- Tip: In this step you really want to level out your surface especially the center panel. Be sure to keep the sander flat and start around the perimeter with one pass and follow into the center panel. Repeat until smooth.



STEP 2:

- Fold a 320 grit film sheet in half and sand the inside corners along with any other high spots.



STEP 3:

- Sand all surfaces with SurfPrep 5 mm fine pad (Recommended to hand sand).



STEP 4:

- Sand all surfaces with SurfPrep 5 mm very fine pad (Recommended to hand sand).



STEP 5:

- Tack and paint!



About this primer:

Introducing ENDURO Undercoat, a remarkable high solids water-based universal primer. With its unique formulation, this primer possesses the capability of being compatible with almost any 1k or 2k water-based primer or finish that can be applied over it.

ENDURO Undercoat is now available for purchase on any paint grade door style. It is also available for sale in both 1 gallon and 5 gallon quantities through our website along with top coats and finish supplies.